


Smart Chime

**MODEL NO.
2000SC**



Model and serial number may be found at the back of the Smart Chime.

Please record both model and serial number in a safe place for future use.

Where Purchased : _____
Date purchased : Month _____
: Day _____
: Year _____
Model No. : _____
Serial # : _____

This Owner's Manual contains information for all models.

Read and keep this manual for future reference.

This manual contains important information on Safety, Assembly, Operation and Maintenance.

Important: This is Owner's Manual for Smart Chime. Please do not discard this.

Congratulations on purchasing the "Smart Chime". Before you can use this appliance you need to follow some simple steps to install Smart Chime.



DO NOT RETURN THE PRODUCT TO THE STORE

Call 1-888 ERGOSYS (1-888-374-6797)

If there are missing parts. Check all packing for missing parts prior to discarding the package.

Before you call us, please have the following information ready.

1. Details of purchase like invoice number (found on the bill or invoice)
2. Name and model number of the product (found on the manual and on the carton.)
3. Actual problem after following the instructions.
4. List of missing parts.

LIMITED WARRANTY

Please read this warranty carefully. Ergo Systems Inc. will warranty this product to be free from manufacturing defects, including workmanship, when assembled and operated according to operating instructions enclosed with this product, for a period of ninety (90) days from the date of original purchase. This warranty is non-transferable and applies solely to the original purchaser and does not extend to subsequent owners of this product. Please register your product at <http://www.autopetfeeder.com>.

1. Repair service for a period of ninety (90) days from the date of original purchase at no charge for parts and labor with proof of purchase.
2. Replacement of defective parts for a period of 12 months from the date of original purchase with proof of purchase. (Labor not included after initial ninety (90) days.)
3. This warranty does not cover cost incurred in the shipping of the product to and from Ergo Systems Inc. for service. Shipping to Ergo Systems Inc. must be prepaid and insured by UPS or other parcel delivery services.

THIS WARRANTY IS VOID IF THE PRODUCT IS:

1. Damaged due to negligence, abuse, misuse, accident, modification, tampering, alteration, faulty installation and / or acts of God.
2. Used for commercial applications or rentals.
3. Modified or repaired by anyone other than Ergo Systems Inc.


The extent of Ergo Systems Inc. under this limited warranty is the repair or replacement of the product at the sole discretion of Ergo Systems Inc. In no event shall Ergo Systems Inc.'s liability exceed the purchase price paid by the purchaser. Under no circumstances shall Ergo Systems Inc. be liable for any loss, direct, indirect, incidental, foreseen, unforeseen, special or consequential damage arising out of or in connection with the use of this product. This warranty is valid only in the United States of America and Canada.

List of parts in the Smart Chime Box



①

Door Switch




②

Chime



③

Pet Switch



④

Mounting Bracket

Components

1. Door Switch
2. Chime
3. Pet Switch
4. Mounting bracket
(Quantity 2)

Installation

Installation of Chime

Step 1

- Mount the bracket on the wall with the screws anywhere inside the home as per your convenience. The bracket has to be mounted in the position as shown in Fig 1.




Fig 1

Step 2

- Fix the Chime on to the bracket by aligning the circle joint in the chime with the projection on the bracket and push towards to your left as shown in Fig 2.




Fig 2

- When the Chime sounds, the chime will signal you that there is someone at the door or your pet is calling for you.




Fig 3


Inbuilt Sounds in Chime

- When the Door Switch is activated it acts as a calling bell.
- When Chime switch is set in the "DOG" mode, it makes a "BARKING" sound.



This switch is located behind the Chime.


- When Chime switch is set in the "CAT" mode, it makes a "MEOWING" sound.



This switch is located behind the Chime.


Installation of Pet Switch

- ❑ The pet switch can be placed anywhere on the floor or it can be mounted on the wall with the help of the bracket provided along with the Door chime according to the pet's convenience.




Step 1

- ❑ Mount the bracket on the wall with the screws in the position as shown in Fig 5.




Step 2

- ❑ Fix the Pet Switch on to the bracket by aligning the circle joint in the Pet Switch with the projection on the bracket and push it downwards as indicated by the arrow shown in Fig 6.



- ❑ The pets can either use their paws to press the switch or their noses to activate the chime.



Installation of Door Switch

Step 1

- ❑ Use a screw driver to lift open the Door Switch cover as shown in Fig 9.




Fig 9

Step 2

- ❑ Place the Door Switch on the wall outside the door by fixing it with screws as shown in Fig 10. Replace the Door Switch cover back in position.




Fig 10




- ❑ This Door Switch functions similar to the calling bell switch which is normally mounted outside your door.



Fig 11

Battery Specifications

Different types of batteries used are	
Chime	: 1.5 V AA Battery (Quantity 3)
Pet Switch	: Standard 9V Battery (Quantity 1)
Door Switch	: 12V 21/23/23A Battery (Quantity 1)



FAQ

1. Are Smart Chimes easy to install?

- Our doorbells are very easy to install.

2. Can I use Smart Chime Outdoors?

- We do not recommend outdoor use.

3. Can the Smart Chime play my favorite song?

- Smart chime can only play the sound of a dog, cat or a door bell ringing sound.

4. Can I toggle between dog tone and cat tone?

- You can toggle between dog tone and cat tone by toggling the switch that is behind the Door Chime.

5. How can my pet signal me with the help of Smart Chime?

- Your pet has to be trained to press Pet Switch to signal you.

6. What is the effective range between the Smart Chime, Door Switch and Pet Switch?

- It can be 100ft diameter or 50ft radius.

7. What is the life time of the batteries in the Smart Chime?

- Batteries can be changed once in 6 months (It also depends on the usage of the Smart Chime by pet. The more the pet uses, often the batteries has to be changed.)

8. How am I to identify the correct set on purchasing the Smart Chime?

- You can identify the correct set by recognizing the same code numbers on all three parts of the Smart Chime set.

9. How can I train my pets to activate the Smart Chime?

- The pet can be trained to either use their paws to press the switch with their noses to activate the chime.
- Teach you pet to press the pet switch and let him/her out and give your pet a treat each time. Continue to do this for about 4 to 6 times a day for about 1 to 2 weeks and your pet should be trained. Some pets may require more or less training than others.

10. Does the Smart Chime require any special maintenance?

- The Smart Chime doesn't require any special maintenance. You need to just replace the batteries as necessary.

Ergo Systems Inc.,

E-Mail
support@ergosys.net

Toll-Free Phone. US only
1-888-ERGOSYS
(1-888-374-6797)

Website
<http://www.autopetfeeder.com>

International Phone
1-630-543-7686



Warranty Registration
<http://www.autopetfeeder.com/warranty.asp>

Fax
1-86-899-5389